

CKM & CKS Series

Yamato

Hanging Dial Scales

The Accu-Weigh® series of hanging dial scales have many applications. They can be used for general weighing or to measure tension, pull or torque. All models are equipped with fine tooth racks, machine cut precision pinions and dual springs to provide the greatest possible accuracy. Made of steel with nickel or zinc plating on all of the internal mechanisms for maximum protection against corrosion.

No special tools are required to access the weighing mechanism, making service and calibration easy to perform. The chart and fine point indicator are protected by a clear, shatterproof plastic cover. There are no weights to handle or slide. Direct weight readings translate into fast, error free weighing. The special design of the indicator virtually eliminates parallax viewing errors and the distinct black on white graduations ensure quick weight determination. The CKM features a dual revolution dial.

Features

- Rugged, All Steel Construction
- Lightweight - Portable
- Fine Point Indicator for Accuracy
- Accurate - Dual Spring Mechanism
- Easy to Read
- Zero Setting Mechanism



Reliability you can trust

Hangging scales

Yamato

Features

- Rugged, All Steel Construction
- Lightweight - Portable
- Fine Point Indicator for Accuracy
- Accurate - Dual Spring Mechanism
- Easy to Read
- Zero Setting Mechanism

Options

- Galvanized Oval Scoop with chain (for CKM-720 & CKM-710K only)
- Stainless Steel Round Pan and 18" Hanger
- Stainless Steel Round Pan and 12" Hanger



Galvanized
Oval Scoop
with Chain



Stainless
Steel Round
Pan with 12"
Hanger

Specifications

| Model | CKM & CKS Series | |
|------------------------|---------------------------------|----------------|
| Weighing System | Dual Spring Mechanism | |
| Capacity and Divisions | Model | Divisions |
| | CKM-710 K* | 10 kg x 20 g |
| | CKM-720* | 20 lb x 1/2 oz |
| | CKS-760 | 60 lb x 4 oz |
| | CKS-7150 | 150 lb x 8 oz |
| CKS-7300 | 300 lb x 1 lb | |
| Material | Enamel Painted Mild Steel | |
| Operating Temperatures | 14° F - 104° F (-10° C - 40° C) | |

*CKM dual revolution. If not ordering with Yamato accessories, please specify dead load.

Accessories

- Calibration Weights



Accu-Weigh
www.YamatoCorp.com

Yamato Corporation
1775 S. Murray Blvd.,
Colorado Springs,
CO 80916 U.S.A.
Tel: 719.591.1500
Fax: 719.591.1045

Yamato Tech Corporation
#112-19425 Langley By-Pass
Surrey, B.C. V3S 6K1
Canada
Tel: 604.533.2338
Fax: 604.533.0827

170C0801